


LINCOLN II

Modificación para configuración 400 canales Modification pour configuration 400 canaux Modification for configuration 400 channels



1 - cortar el hilo blanco (L503) - couper le fil blanc (L503) - cut the white wire (L503)

<i>bajos - inférieurs - inferior</i>		<i>altos - supérieurs - superior</i>
Banda - Bande - Band (40 CH)	A	
Banda - Bande - Band (40 CH)	C	b Banda - Bande - Band (40 CH)
Banda - Bande - Band (40 CH)	E	d Banda - Bande - Band (40 CH)
Banda - Bande - Band (40 CH)	G	F Banda - Bande - Band (40 CH)
		H Banda - Bande - Band (40 CH)
		I Banda - Bande - Band (40 CH)
		J Banda - Bande - Band (40 CH)

25615 Mhz <.....> 30105 Mhz

2 - Pulse 9/19 para volver a la banda A - canal de 9 o 19

2 - Pressez 9/19 pour retourner à la bande A - canal 9 ou 19

2 - Press 9/19 to return to the band A - channel 9 or 19